

# PROGRESS

## LT sway bars

### INSTALLATION INSTRUCTIONS

Rear Sway Bar  
2001-2011 Chevrolet Trailblazer  
Part # 22.0431.000  
No Revision 1/14/2022

#### WHO SHOULD INSTALL THIS PRODUCT?

Progress LT suspension products should only be installed by a qualified licensed mechanic experienced in the installation and removal of suspension components. Please read instructions from start to finish and verify the parts in the parts list before beginning installation. Some vehicles may have interference problems with installation due to exhaust modifications or aftermarket systems.

#### Parts List

Description	Quantity	Description	Quantity
27mm Solid Rear Sway Bar	1	Bushing	2
Lube	1		

1. Park vehicle on a smooth, level, asphalt or concrete surface. Block front wheels. Jack up rear end of vehicle and support frame with jack stands.
2. Locate and remove the nuts that attach the ends of the OEM sway bar to the end links and save for re-installation. You may have to use an allen wrench to hold the stud as you remove the nut.
3. Next, remove the nuts holding the bushing brackets to the rear axle mounts. Remove the bar with the bushings from the vehicle. Keep all the hardware and brackets for reinstallation.
4. Liberally grease the inner bore of the new polyurethane bushings with lubricant provided. Open the bushings and place them over the bar as positioned on the stock bar. Place OE bracket over the bushings and torque to 38-42 ft/lbs.



OE Style Replacement polyurethane bushing



The bar is shown with the end link in the firm setting.

5. This is an adjustable sway bar, the mounting hole toward the end of the bar is the softer setting. Reattach the end links to desired setting and torque all hardware to 38-42 ft/lbs.
6. Installation is now complete, periodically check bar for tightness and apply grease as necessary.

### **Torque Check**

<b>Hardware</b>	<b>Torque</b>
Bushing Bracket Hardware	38-42 ft/lbs
End link Nuts	38-42 ft/lbs

**Thank you for choosing Progress LT sway bars.  
For additional product and technical information, visit our websites.**