



INSTALLATION INSTRUCTIONS

Progress Technology Rear Anti-Sway Bar

PT Cruiser

Part #62.0610

No Revision (03/29/2001)

WHO SHOULD INSTALL THIS PRODUCT?

Progress Technology products should only be installed by a qualified licensed mechanic experienced in the installation and removal of suspension components. Please read instructions from start to finish and verify the parts in the parts list before beginning installation.

Parts List

Description	Quantity
22mm Sway Bar	1
Bushing	2
Lube	1

1. Park vehicle on a smooth, level, asphalt or concrete surface. Block front wheels. Jack up rear end of vehicle and support with jackstands. Remove original equipment anti-sway bar, noting the original orientation of the bar, brackets, and end-link configuration.
2. Remove the rear bracket assemblies from the factory rear bar. You will need to bend open the locking tab that holds the two pieces together on each bracket.
3. Locate the round polyurethane bushings and tube of special grease supplied in the hardware kit. Cut the end off of the grease tube and apply the grease to the bore of the polyurethane bushings (in the hole). Open the bushings and snap them over the new Anti-roll Bar, as positioned on the stock bar. Using the stock (OEM) hardware, attach the bar and brackets to the stock mounting locations. Tighten the mounting bolts.
4. Install the stock end-link assemblies to the ends of the bar. Tighten the end links.
5. Lower rear of vehicle onto ground, and roll car back and forth to settle suspension.
6. Installation is complete. Check assembly periodically for tightness.

**Thank you for choosing Progress products.
For additional product and technical information, visit our website.**