



## INSTALLATION INSTRUCTIONS

Progress Technology Rear Anti-Sway Bar  
2009-2014 Toyota Corolla / 2009-2013 Toyota Matrix  
Part # 62.2151  
No Revision (7/14/2011)

### WHO SHOULD INSTALL THIS PRODUCT?

Progress Technology products should only be installed by a qualified licensed mechanic experienced in the installation and removal of suspension components. Please read instructions from start to finish and verify the parts in the parts list before beginning installation.

### Parts List

<u>Item</u>	<u>Quantity</u>
Anti-roll bar (24 mm)	1

1. Park vehicle on a smooth, level, asphalt or concrete surface. Block front wheels. Jack up rear end of car and support with jackstands.
2. Remove the bolts that hold the bar between the beam. Remove the stock bar.



3. Install your new PROGRESS anti-roll bar as shown. Torque bolts to factory specifications. Lower rear of car onto ground, and roll car back and forth to settle suspension.
4. Installation is complete. Check assembly periodically for tightness.

**Thank you for choosing Progress products. For additional product and technical information, visit our website.**