



INSTALLATION INSTRUCTIONS

Progress Technology End link kit

C5/C6 Corvette

Part # 67.50.0480

No Revision (5/20/2021)

WHO SHOULD INSTALL THIS PRODUCT?

Progress Technology products should only be installed by a qualified licensed mechanic experienced in the installation and removal of suspension components.



- Assemble as shown.
- Factory mounts need to be drilled to 1/2"
- Taper on bolt head and spacer faces rod end.
- Use a dab of lube (supplied) on each nut.
- Torque bolt 48-52 ft/lbs